

LED Stage Lighting Operating Manual

60W RGB 3in1LED Par Light



Please Read Over This Manual before Operating the Light Fixture

DMX MODE

4 Channels Mode (d001)

Channel	Function	Instruction
CH1	R Dimmer	Dimmer- Dark to Bright
CH2	G Dimmer	Dimmer- Dark to Bright
CH3	B Dimmer	Dimmer- Dark to Bright

8 Channels Mode (A001)

Channel	Function	Instruction
CH1	Total Dimmer	RGBW Total Dimmer- Dark to Bright
CH2	R Dimmer	Red Dimmer- Dark to Bright
CH3	G Dimmer	Green Dimmer- Dark to Bright
CH4	B Dimmer	Blue Dimmer- Dark to Bright
CH5	Total Strobe	RGBW Total Flash Strobe, 005-255 Slow to Fast
CH6	Function Choice	000~050: CH1-CH6 Control. 051~100: Different Colors output 101~150: Colors Jump Change. 151~200: Colors Gradate. 201~250: Colors Pulse Change. 251~255: Sound-Active
CH7	Function/Speed	Slow to Fast (At the Colors output choose the color)

KEYS INSTRUCTION



MENU



UP



DOWN



ENTER

DIGITAL SHOW FUNCTION FORM

No	Show	Function	Value	Instruction
1	d001	DMX address	001~512	4CH mode UP,DOWN increase or reduce the value
2	A001	DMX address	001~512	8CH mode UP,DOWN increase or reduce the value
3	r255	Red dim	000~255	UP,DOWN Change brightness
4	G255	Green dim	000~255	UP,DOWN Change brightness
5	b255	Blue dim	000~255	UP,DOWN Change brightness
6	F255	Strobe	010 ~ 255	UP,DOWN change the speed
7	CC15	Colors Jump	00 ~ 15	UP,DOWN change the speed
8	DE15	Colors Gradate	00 ~ 15	UP,DOWN change the speed
9	CP15	Colors	00 ~ 15	UP,DOWN change the speed
10	SoUd	sound-Acti	/	Sound-Active

Technical:

Voltage: AC110-220V 50/60HZ

Light source: 1pcs*60w

Color: RGB 3IN1 LEDs

Channel:3/7CH

Operation: DMX512, Auto, Sound, Master-slave