



FX BAR 5050



User Manual

WWW.JMAZLIGHTING.COM

The JMAZ FX BAR 5050 is the next generation of light bars. Choose from one of the endless built-in shows, preset a certain color or simply run it in sound active mode, the FX BAR 5050 is versatile and a must-have at your next event. With an all-aluminum case serving as a heatsink, the FX BAR 5050 has no fans, which means it will run smooth and quiet. Loaded with a powerhouse of SMD's and LED's, the FX BAR 5050 has RGB outer SMD's, Ultra-White inner SMD's and 12 warm white round LED's. Perfect for photography and video production or if you want to use them in your corporate events, studio, background or main stage lighting, bands, decorating your bar or night club, with the FX BAR 5050, the applications are endless.

SPECIFICATIONS

- Power Consumption:150W
- 96 x RGB Outer SMDs (For A Light Show Or Ambient Lighting/wash Effect)
- 144 x Ultra-white Inner SMDs (For A Strong Strobe Effect Or Bright Illumination)
- 12 X 5W Warm White Beams (For A Blinding Effect, Ambient Lighting Or Photography/Video Production)
- Operation: DMX512, Auto, Sound Active, Master/Slave, And Manual Modes
- Channel: 10/18/23/28/33/61 DMX Channel Mode
- Adjustable Mounting Brackets Are Included, Compatible With O-type Clamp (O-clamp Sold Separately).

MENU

No	Show	Function	Instruction
1	d001	DMX Address (001~512)	DMX-512 address set
		CH10	CH-10、CH-48、CH-51
2	CL01	Different Colors Output (01~22)	UP 、 DOWN Change brightness
3	FH99	Strobe flash (01~99)	UP、DOWN Change the speed
4	1JP8	Effict 1 (1~9)	UP、DOWN Change the speed
5	2JP8	Effict 2 (1~9)	UP、DOWN Change the speed
6	3JP8	Effict 3 (1~9)	UP、DOWN Change the speed
7	4JP8	Effict 4 (1~9)	UP、DOWN Change the speed
8	5JP8	Effict 5 (1~9)	UP、DOWN Change the speed
9	6JP8	Effict 6 (1~9)	UP、DOWN Change the speed
10	7JP8	Effict 7 (1~9)	UP、DOWN Change the speed
11	8JP8	Effict 8 (1~9)	UP、DOWN Change the speed
12	9JP8	Effict 9 (1~9)	UP、DOWN Change the speed

18Channels	
CH1	Fixture Dimmer
CH2	5W warm strobe from slow to fast
CH3	5W warm 12pcs dimmer 0-100%
CH4	5W warm 12pcs program effect 1-20
CH5	5W warm 12pcs program effect speed from slow to fast
CH6	white strobe LED strobe from slow to fast
CH7	white strobe LED 12 group dimmer 0-100%
CH8	white strobe LED 12 group program effect 1-20
CH9	white strobe LED 12 group program effect speed from slow to fast
CH10	RGB LED strobe from slow to fast
CH11	RGB LED RED 8 group dimmer 0-100%
CH12	RGB LED GREEN 8 group dimmer 0-100%
CH13	RGB LED BLUE 8 group dimmer 0-100%
CH14	RGB LED program effect 1-20
CH15	RGB LED program effect speed from slow to fast
CH16	Program effect auto
CH17	effect program speed
CH18	sound control (sensitivity from low to high)

23Channels	
CH1	Fixture Dimmer
CH2	5W warm white strobe
CH3	5W warm white 6 group1
CH4	5W warm white 6 group2
CH5	5W warm 12pcs program effect 1-20
CH6	5W warm 12pcs program effect speed from slow to fast
CH7	white strobe LED strobe
CH8	white strobe LED 6 group1
CH9	white strobe LED 6 group2
CH10	white strobe LED 12 group program effect 1-20
CH11	white strobe LED 12 group program effect speed from slow to fast
CH12	RGB LED strobe
CH13	RGB LED RED 4 group 1
CH14	RGB LED GREEN 4 group 1
CH15	RGB LED BLUE 4 group 1
CH16	RGB LED RED 4 group 2
CH17	RGB LED GREEN 4 group 2
CH18	RGB LED BLUE 4 group 2
CH19	RGB LED program effect 1-20
CH20	RGB LED program effect speed from slow to fast
CH21	Program effect auto
CH22	effect program speed

CH23	sound control (sensitivity from low to high)
28 Channels	
CH1	Fixture Dimmer
CH2	5W warm white strobe
CH3	5W warm white 4 group1
CH4	5W warm white 4 group2
CH5	5W warm white 4 group3
CH6	5W warm 12pcs program effect 1-20
CH7	5W warm 12pcs program effect speed from slow to fast
CH8	white strobe LED strobe
CH9	white strobe LED 4 group1
CH10	white strobe LED 4 group2
CH11	white strobe LED 4 group3
CH12	white strobe LED 12 group program effect 1-20
CH13	white strobe LED 12 group program effect speed from slow to fast
CH14	RGB LED strobe
CH15	RGB LED RED3 group1
CH16	RGB LED GREEN 3 group1
CH17	RGB LED BLUE 3 group1
CH18	RGB LED RED 2 group 2
CH19	RGB LED GREEN 2 group 2
CH20	RGB LED BLUE 2 group 2
CH21	RGB LED RED3 group3
CH22	RGB LED GREEN 3 group3
CH23	RGB LED BLUE 3 group3
CH24	RGB LED program effect 1-20
CH25	RGB LED program effect speed from slow to fast

CH26	Program effect auto
CH27	effect program speed
CH28	sound control (sensitivity from low to high)
33Channels	
CH1	Fixture Dimmer
CH2	5W warm white strobe
CH3	5W warm white 3 group1
CH4	5W warm white 3 group2
CH5	5W warm white 3 group3
CH6	5W warm white 3 group4
CH7	5W warm 12pcs program effect 1-20
CH8	5W warm 12pcs program effect speed from slow to fast
CH9	white strobe LED strobe
CH10	white strobe LED 3 group1
CH11	white strobe LED 3 group2
CH12	white strobe LED 3 group3
CH13	white strobe LED 3 group4
CH14	white strobe LED 12 group program effect 1-20
CH15	white strobe LED 12 group program effect speed from slow to fast
CH16	RGB LED strobe
CH17	RGB LED RED2 group1
CH18	RGB LED GREEN 2 group1
CH19	RGB LED BLUE 2 group1
CH20	RGB LED RED2 group2

CH21	RGB LED GREEN 2 group2
CH22	RGB LED BLUE 2 group2
CH23	RGB LED RED2 group3
CH24	RGB LED GREEN 2 group3
CH25	RGB LED BLUE 2 group3
CH26	RGB LED RED2 group4
CH27	RGB LED GREEN 2 group4
CH28	RGB LED BLUE 2 group4
CH29	RGB LED program effect 1-20
CH30	RGB LED program effect speed from slow to fast
CH31	Program effect auto
CH32	effect program speed
CH33	sound control (sensitivity from low to high)
61 Channels	
CH1	Fixture Dimmer
CH2	5W warm white strobe
CH3	5W warm white 1
CH4	5W warm white 2
CH5	5W warm white 3
CH6	5W warm white 4
CH7	5W warm white 5
CH8	5W warm white 6
CH9	5W warm white 7
CH10	5W warm white 8
CH11	5W warm white 9
CH12	5W warm white 10
CH13	5W warm white 11
CH14	5W warm white 12

CH15	5W warm 12pcs program effect 1-20
CH16	5W warm 12pcs program effect speed from slow to fast
CH17	white strobe LED strobe
CH18	white strobe LED 1 group1
CH19	white strobe LED 1 group2
CH20	white strobe LED 1 group3
CH21	white strobe LED 1 group4
CH22	white strobe LED 1 group5
CH23	white strobe LED 1 group6
CH24	white strobe LED 1 group7
CH25	white strobe LED 1 group8
CH26	white strobe LED 1 group9
CH27	white strobe LED 1 group10
CH28	white strobe LED 1 group11
CH29	white strobe LED 1 group12
CH30	white strobe LED 12 group program effect 1-20
CH31	white strobe LED 12 group program effect speed from slow to fast
CH32	RGB LED strobe
CH33	RGB LED RED1 group1
CH34	RGB LED GREEN 1 group1
CH35	RGB LED BLUE 1 group1
CH36	RGB LED RED 1 group2
CH37	RGB LED GREEN 1 group2
CH38	RGB LED BLUE 1 group2
CH39	RGB LED RED1 group3
CH40	RGB LED GREEN 1 group3
CH41	RGB LED BLUE 1 group3
CH42	RGB LED RED 1 group4
CH43	RGB LED GREEN 1 group4
CH44	RGB LED BLUE 1 group4
CH45	RGB LED RED1 group5
CH46	RGB LED GREEN 1 group5
CH47	RGB LED BLUE 1 group5
CH48	RGB LED RED 1 group6

CH49	RGB LED GREEN 1 group6
CH50	RGB LED BLUE 1 group6
CH51	RGB LED RED1 group7
CH52	RGB LED GREEN 1 group7
CH53	RGB LED BLUE 1 group7
CH54	RGB LED RED 1 group8
CH55	RGB LED GREEN 1 group8
CH56	RGB LED BLUE 1 group9
CH57	RGB LED program effect 1-20
CH58	RGB LED program effect speed from slow to fast
CH59	Program effect auto
CH60	effect program speed
CH61	sound control (sensitivity from low to high)