


## MENU NAVIGATION



Ch1: 0-3 light OFF, 4-9 light ON, 10-39 strobe (from slow to fast), 40-69 fade in/out (from slow to fast), 70-99 auto colour change, 100-110 chase1, 111-121 chase2, 122-132 chase3, 133-143 chase4, 144-154 chase5, 155-165 chase6, 166-176 chase7, 177-187 chase8, 188-198 chase9, 199-209 chase10, 210-220 chase11, 221-231 chase12, 232-255 chase13

Ch2: 0-255 main dimmer (from 0 to 100%)

Ch3: 0-255 red dimmer Ch4: 0-255 green dimmer

Ch5: 0-255 blue dimmer

DMX CHART (5CH mode)

ATTENZIONE: SELEZIONARE LA FUNZIONE DESIDERATA E LASCIARE ACCESA LA STRIP LED RGB ALMENO 8 MINUTI

WARNING: ONCE SET THE NEW FUNCTION, IN ORDER TO FIX IT, LEAVE THE STRIP LED TURNED ON FOR AT LEAST 8 MINUTES

Ch1: light OFF 0-3 light ON 4-9 strobe (from slow to fast) 10-39 fade in/out (from slow to fast) 40-69 auto colour change 70-99 auto colour change 100-110 chase1, 111-121 chase2, 122-132 chase3, 133-143 chase4, 144-154 chase5, 155-165 chase6, 166-176 chase7, 177-187 chase8, 188-198 chase9, 199-209 chase10, 210-220 chase11, 221-231 chase12, 232-255 chase13

Ch2: 0-255 main dimmer (from 0 to 100%)

Ch3: 0-255 red 1st segment dimmer

Ch4: 0-255 green 1st segment dimmer

Ch5: 0-255 blue 1st segment dimmer

Ch6: 0-255 red 2nd segment dimmer

Ch7: 0-255 green 2nd segment dimmer

Ch8: 0-255 blue 2nd segment dimmer

Ch9: 0-255 red 3rd segment dimmer

Ch10: 0-255 green 3rd segment dimmer

Ch11: 0-255 blue 3rd segment dimmer

Ch12: 0-255 red 4th segment dimmer

Ch13: 0-255 green 4th segment dimmer

Ch14: 0-255 blue 4th segment dimmer

Ch1: light OFF, 4-9 light ON, 10-39 strobe (from slow to fast), 40-69 fade in/out (from slow to fast), 70-99 auto colour change, 100-110 chase1, 111-121 chase2, 122-132 chase3, 133-143 chase4, 144-154 chase5, 155-165 chase6, 166-176 chase7, 177-187 chase8, 188-198 chase9, 199-209 chase10, 210-220 chase11, 221-231 chase12, 232-255 chase13

Ch2: 0-255 main dimmer (from 0 to 100%)

Ch3: 0-255 red half bar dimmer

Ch4: 0-255 green half bar dimmer

Ch5: 0-255 blue half bar dimmer

Ch6: 0-255 red half bar dimmer


Ch7: 0-255 green half bar dimmer

Ch8: 0-255 blue half bar dimmer

DMX CHART (8CH mode)

## STRIP LED RGB

CODE K2014



**PSL**  
professional supplies



Prima di utilizzare l'apparecchio leggere le seguenti istruzioni

Grazie di avere scelto un articolo della linea di luci prodotta dalla PSL.

Confidiamo che la scelta soddisfi le vostre esigenze e faremo il possibile per aiutarvi affinché questo si realizzi.

Prima di utilizzare l'apparecchio leggete attentamente il manuale di servizio e d'uso dello stesso.

### PRECAUZIONI PER LA SICUREZZA

- Non apportare modifiche all'apparecchio.
- Evitare che nell'apparecchio penetrino liquidi infiammabili, acqua oggetti metallici e comunque qualsiasi oggetto.
- Installare l'apparecchio fuori dalla portata delle persone.
- Il montaggio ed il collegamento dell'apparecchio deve essere fatto solo da personale specializzato.
- Fissare sempre il cavo di sicurezza all'apparecchio.
- Non utilizzare in luoghi con eccessive vibrazioni.
- Evitare l'uso con temperatura ambiente superiore ai 40°C o inferiori a 0°C.
- Evitare di usare l'apparecchio in luoghi polverosi.
- Per la pulizia interna rivolgersi ad un tecnico qualificato.
- Per una buona resa pulire frequentemente il vetro di protezione.
- Pulire esternamente l'apparecchio con prodotti appropriati.
- Non aprire l'apparecchio per nessun motivo.
- Per eventuali interventi necessari alle riparazioni, sarà tassativo ricorrere a personale autorizzato.

### Messa in opera

Questo apparecchio deve essere utilizzato con una tensione di 220/240Volts 50 Hz. Controllare che la tensione di utilizzo sia quella indicata nell'apposita etichetta posta sull'apparecchio. L'apparecchio può funzionare in SOUND oppure può essere controllato via DMX.

Before operating, read and understand the user's manual.

Congratulations on the purchase of your new PSL lighting effect. We are confident you will enjoy many trouble free hours with this unit. To assist with the care and use of the product we have prepared this short guide.

### SAFETY PRECAUTIONS

- Do not modify any parts of the unit.
- Make certain that no inflammable liquids, water, metallic objects or any other foreign bodies enter the unit.
- Install the unit in such a position that it is out of people's reach.
- The unit must be installed and connected by specialized personnel.
- Always connect a safety retaining chain
- Do not use in damp surroundings.
- Do not use in places subject to excessive vibrations.
- Make certain that the surrounding temperature is never more than 40°C or less than 10°C.
- Avoid using the unit in dusty surroundings.
- For internal cleaning, contact a qualified technician.
- To ensure good light output, clean lens frequently.
- The outside of the unit must only be cleaned with suitable products.
- Do not open the unit for any reason.
- If any repairs are necessary, make certain that they are only carried out by qualified personnel.

### Operation

This lighting effect has been designed to function on a mains power supply of either 230V~50Hz and has been fitted with a suitable power plug for use with your local voltage. Check the label on the unit and the power plug for the correct voltage. Can be SOUND activated or it can be controlled via DMX 512.

### Installation / Mounting