



Sends ArtNet directly (but over the LAN, of course) to the IP address (ArtNet universe 1)

Could send ArtNet data to the output node

DMX OUT

DMX cable

LAN, IP: 192.168.2.55 (static)

DMX cable

LAN, IP: 192.168.2.133 (static)

DMX IN

Should receive ArtNet data from the input node (ArtNet universe 0)

LAN, IP: 192.168.2.21 (DHCP)

W-LAN, IP: 192.168.2.25 (DHCP)